

Decagon Leaf Wetness Sensor - Installation

The leaf wetness sensor is designed to be deployed either in the canopy or on weather station masts. There are two holes in the non-sensing portion of the sensor body for mounting. The holes can be used with either zip ties or with 4-40 bolts.

